

### SERVICE INSTRUCTION CK-SI004 Rev NC

EFFECTIVE DATE: This Service Instruction is effective April 8, 2022

**SUBJECT**: IGNITION COIL BRACKET RETROFIT

MODELS AFFECTED: CCK-1865 Kits shipped prior to June, 2021

CCX-1865 S/N 0001-0030

COMPLIANCE TIME: This retrofit is optional and is left to the sole discretion of the

owner / operator / builder of the Experimental Amateur-Built aircraft unless retrofit is called for as part of other service document(s), or becomes necessary due to coil replacement. The shape and mounting pattern of the ignition coils on CC340 engines was revised due to Lightspeed Engineering supplier

**Page** 1 of 5

changes following the S/N range above.

**PURPOSE:** Should it be necessary to change to the new style ignition coils,

this document is provided to guide installation of the additional

mounting brackets required to support newer style coils.

**WARRANTY:** This change is optional, and is not considered a warranty item.

**PARTS LIST:** 

PART	DESCRIPTION	QTY
SC55024-001	Stay Bracket, Ignition Coil	1
SC55022-003	Lower Ignition Coil Bracket	2
AN960-416	Washer	16
AN960-10	Washer	12
AN936-A516	Lock Washer	2
AN363-1032	Nut	6
AN363-428	Nut	8
AN4-12A	Bolt	8
AN3-5A	Bolt	6
SP55020-217	Spade Connector (18-22 AWG, RED)	4
SP55020-218	Spade Connector (10-12 AWG, YLW)	4
(SP55020-114)	(Ignition Coil)	REF
(SP55020-112)	(Ignition Coil Wires)	REF
(VP7109-002)	(heat shrink for wire shield)	REF



## SERVICE INSTRUCTION CK-S1004

Rev NC

Page 2 of 5

#### **INSTRUCTIONS:**

- 1. Read all instructions before beginning any work.
- 2. Remove the engine cowling per the Aircraft Maintenance Manual (CK10000AMM).
- 3. Label each spark plug wire and corresponding ignition wire (the spade connection opposite each spark-plug wire stud) as shown in Figure 1. Then remove the spark plug wires and ignition wires from the ignition coils.



FIGURE 1 - SPARK PLUG AND IGNITION WIRE LABELING

- **4.** Remove the ignition coils from the mounting bracket.
- **5.** Remove and retain the nuts from the forward two carburetor mounting studs. Discard the washers from under these nuts.
- **6.** Replace the angled spade connectors on each ignition wire (8 total) with straight spade connectors. Red connectors (SP55020-217) go on the center conductor, and yellow connectors (SP55020-218) go on the shield.



### SERVICE INSTRUCTION CK-SI004 Rev NC Page 3 of 5

7. Install SC55022-003 brackets on each of the two vertical portions of the existing bracket as shown in Figure 2. Note that the longer coil mounting tabs on SC55022-003 brackets should be positioned outboard of the existing bracket. (This will position the outer two coils slightly forward of the center two coils).




FIGURE 2 – COIL INSTALLATION

- **8.** Install the new style ignition coils on the SC55024-001 brackets as shown in Figure 2. Note that hardware is easiest to access if the center two coils are mounted on their respective brackets before mounting the brackets in Step 7. The outer two coils should be installed after the brackets are mounted.
- **9.** Install the SC55024-001 stay bracket between the SC55022-003 brackets and the two forward carburetor mounting studs as shown in Figure 2. Use the two original carburetor nuts removed in step 5, each with a new AN936-A516 washer. Apply torque stripe after torqueing.
- 10. Install the spark plug wires and corresponding ignition wires as shown in Figure 3. Note that the two ignition wires and the two spark plug wires connected to each coil are not polarity-sensitive. Ensure plug wires click and seat fully onto studs. Ensure spade connectors fit tightly onto the coil, and ignition wires have proper slack, referring to SK-SB010 for more detail. Should it be necessary to replace the ignition wires to achieve proper slack, wire and heat shrink part numbers are given as reference in the parts list. Spark plug wire part number information is given in Appendix A.



#### SERVICE INSTRUCTION CK-S1004

Rev NC Page 4 of 5




FIGURE 3 – IGNITION COIL CONNECTIONS

- **11.** Bundle and support spark plug and ignition wires, adjusting routing to avoid tension on connectors and abrasion on wires. Ignition coax and spark plug wires may be routed together but a minimum of ½" separation should be maintained between these and sensor wires such as carb temp sensor (if equipped) and crank position sensor wires. Use standoffs as necessary.
- **12.** Perform a final check and general inspection, and reinstall the engine cowling.
- **13.** Perform an engine-run on the ground, checking for correct ignition operation per POH/AFM "Before Takeoff" procedures. If problems are found, verify connections per Figure 3 and re-check operation.
- **14.** Make logbook entry stating that ignition coils were replaced and CK-SI004 Rev NC was complied with. Change to weight and balance is +1.5 lb at an arm of 18".

If you are no longer in possession of this aircraft, please forward this information to the present owner/operator and notify Cub Crafters, Inc. Contact the customer service department at:

Cub Crafters, Inc. 1918 S. 16<sup>th</sup> Avenue Yakima, WA 98903. 1-877-484-7865 or 1-509-248-9491 support@cubcrafters.com

Please include the aircraft registration number, serial number, current name, and address of the owner and/or operator.

Form #: EN-555 Rev B, 01-23-2015



# SERVICE INSTRUCTION CK-SI004 Rev NC

**Page** 5 of 5

#### APPENDIX A - SPARK PLUG WIRE INFORMATION



PART NO.	POSITION	1
SP55020-133	<b>ΒΟΠΟΜ #4</b>	22"
SP55020-102	воттом #3	13"
SP55020-132	<b>BOTTOM #2</b>	15"
SP55020-107	BOTTOM #1	19"
SP55020-134	TOP #4	26"
SP55020-135	TOP #3	29"
SP55020-108	TOP #2	23"
SP55020-136	TOP #1	33"

HIGH TENSION LEAD DETAILS